

COFFER

24" 24" 24" 40" range w/hood 24" 24" uppers uppers


base w/shelves (no drawer) 24" open from dining room

24" base 24" base 24" base 36" base 24" drawer base

24" base 24" base

PANTRY

24" base 36" sink base 24" DW



4 x 21" bases

above fridge